



CASE STUDY /

Semiconductor Wearout Life Prediction

A major auto manufacturer was concerned with the reliability of semiconductor components that are part of a PCBA housed inside a transmission controller under the hood. The unit is exposed to extreme conditions such as high temperature and humidity from heat generated while running and solar heating while parked. The auto manufacturer requested a wearout life prediction analysis on potential high-risk components.


/ Approach

Ansys-DfR Solutions first ran a reliability analysis using Ansys Sherlock simulations on separate semiconductor components that comprise the PCBA, including several components in different technology nodes. These simulations were used to predict the lifetime of the components by accelerating the rate of failure mechanisms. High risk components were determined based on their process node. These simulations took into account integrated circuit wearout and aging due to electromigration (EM) of interconnects, time dependent dielectric breakdown (TDDB) of dielectric materials and transistor degradation phenomena such as bias temperature instability (BTI) and hot carrier injection (HCI). Component level reliability analysis was performed on each component, taking into consideration the operating conditions of the IC and test conditions as demonstrated by the manufacturer.

Results included failure probability and lifetime prediction for each component due to a combination of the mechanisms mentioned above. This analysis helped identify the component(s) in the PCBA that are susceptible to early wearout failure.

/ Recommendation

- Determine if each component meets the life expectancy of the system.
- Identify contributing factors for each component that drives early life failure.
- Propose changes in operating conditions/parameters that are likely to mitigate the lifetime reduction.



Life prediction as a function of four intrinsic semiconductor failures.

/ Results

Based on the analysis, the customer was able to predict the components that showed early lifetime degradation and was able to mitigate risks by adjusting factors such as voltage, temperature and duty cycle of operation.

ANSYS, Inc.
 Southpointe
 2600 Ansys Drive
 Canonsburg, PA 15317
 U.S.A.
 724.746.3304
 ansysinfo@ansys.com

If you've ever seen a rocket launch, flown on an airplane, driven a car, used a computer, touched a mobile device, crossed a bridge or put on wearable technology, chances are you've used a product where Ansys software played a critical role in its creation. Ansys is the global leader in engineering simulation. We help the world's most innovative companies deliver radically better products to their customers. By offering the best and broadest portfolio of engineering simulation software, we help them solve the most complex design challenges and engineer products limited only by imagination.

Visit www.ansys.com for more information.

Any and all ANSYS, Inc. brand, product, service and feature names, logos and slogans are registered trademarks or trademarks of ANSYS, Inc. or its subsidiaries in the United States or other countries. All other brand, product, service and feature names or trademarks are the property of their respective owners.

© 2021 ANSYS, Inc. All Rights Reserved.